10-Dock Assembly Steps

Includes: 1 Dock, 30 Refills, 10 Repellers



Step 1: Remove all contents from the box

Carefully unpack all components from the packaging. Lay them out on a clean, flat surface and inspect each item for any damage or missing parts.

Step 2: Place the Dock on a firm, flat surface



Step 3: Plug the Dock into a power source





The cord is located on the back of the dock.

Step 4: Remove all Repellers from packaging and place onto chargers on the dock



Step 5: Insert 20 refill units into the empty storage slots in the Dock



Step 6: When using Repeller, remove from Dock and remove top cap from Repeller



Step 7: Take one refill and remove the cap, place cap in refill storage area





Step 8: Insert the refill into the Repeller securely





Step 9: Replace the top cap on the Repeller



Step 10: Once Repeller is turned on, the Repeller is ready to be used





Step 11: Place the dock cover onto the dock and move inside when charging overnight



Assembly Complete!

Notes:

- **Ensure each refill is fully inserted before replacing the Repeller top cover**
- **Keep the dock on a stable surface during charging and storage**
- **For prolonged periods of storage or disuse, remove refills and replace cap**