




HECTOR FINCH


PEN ADJUSTABLE PENDANT LAMP MEDIUM



PRODUCT CODE PL423M

CATEGORY: CHANDELIERS & PENDANTS

DIMENSIONS





HECTOR FINCH

PRODUCT CODE PL423M

CATEGORY: CHANDELIERS & PENDANTS

PEN ADJUSTABLE PENDANT LAMP MEDIUM

LAMP TYPE	USA 3 x LED-Line 150 (Incl.)
FINISH OPTIONS	Brass Polished Lacquered, Brass Brushed Lacquered, Chrome, Nickel Polished (shown) and Nickel Matte.
SIZE & SIMILAR OPTIONS	Pen Adjustable Pendant Lamp Small (PL423S) and Pen Adjustable Pendant Lamp Large (PL423L).
WEIGHT	7lb 8oz
ADDITIONAL INFORMATION	120 V bulbs not included.
CLEANING AND MAINTENANCE INSTRUCTIONS	Metalwork: We recommend a light polish with a non-abrasive lint free cloth. Do not use any metal cleaning products on the fixture as it can remove the finish entirely. Unlacquered brass finish will patinate slowly over time and can be brightened to brass by the use of a brass cleaning agent.



INSTALLATION INSTRUCTIONS



1. Lay out the lamp parts on the floor.


PEN 100 consists of:
1 x ceiling - mounting rail
(incl. Ardit LED control gear)
1 x Canopy
2 x sway bars
1 x lamp body (contains 2 x LED Line 150)



2. Pendulum poles through the canopy into the ceiling mounting rail. Screw in the ceiling mounting rail. Counter with Allen screw.
ATTENTION: Red marked side of the canopy must be connected to the hole in the screen, where the black ring is.




3. Screw the pendant rods into the lamp body. ATTENTION: Red marked side of the canopy must be connected to the hole in the screen, where the black ring is.



4. Attach the light to the ceiling. (Easier with an assistant.)



5. Make the electrical connection. (Only by electricians.)



6. Push up canopy with adjusting rings and counter.