

# PROTECTING PROFESSIONALS FROM POTENTIAL FENTANYL EXPOSURE.



First Defense™ Wipes provide a safe, fast, and convenient way to detect potential fentanyl on surfaces, helping reduce harm to professionals who may be exposed to this dangerous substance.

These easy-to-use wipes are designed for professional use only and are a key tool for risk mitigation.

## WHY CHOOSE FIRST DEFENSE™ WIPES?







**SAFE:** Formulated with plant-based technology and environmentally friendly ingredients.

**FAST:** Delivers presumptive results quickly with a clear color-change indicator.

**CONVENIENT:** Single-use wipes packaged for portability and instant results.

**EFFECTIVE:** Helps professionals take preventive steps to reduce exposure risks.

## DIRECTIONS FOR USE

-  **1. PROTECT YOURSELF:** Put on nitrile exam gloves.
-  **2. PREPARE:** Open a single-use wipe. Use immediately.
-  **3. TEST THE SURFACE:** Wipe the suspected area thoroughly.
-  **4. CHECK RESULTS:** Observe for a color-change indicator if fentanyl is present.
-  **5. DISPOSE SAFELY:** Follow your department's disposal protocol.
-  **6. CLEAN UP:** Wash hands with soap and warm water.

## PACKAGING OPTIONS

- Sleeve = 25 wipes
- Box = 100 wipes (4 sleeves)
- Case = 1,000 wipes (10 boxes)



## PRODUCT DETAILS

- **Warnings:** Not recommended for use on human skin or diagnosing medical conditions. Not intended for testing trace evidence on skin. Causes serious eye irritation. IF IN EYES: Rinse cautiously with water for several minutes. If eye irritation persists, get medical advice/attention.
- **Disclaimer:** First Defense™ is a risk mitigation tool, not a drug test. Due to the variations and constantly changing nature of available street drugs, wipes may yield rare false positives and false negatives. Use responsibly: always wear nitrile exam gloves. For harm-reduction and awareness purposes only. Do not treat as a definitive test.
- **Ingredients:** Utilizes plant-based technology.
- **Storage:** Keep cool, out of direct sunlight, and away from ignition sources.



Distributed By  
**NOBLE | IQ**

Contact Edward M. Levy  
Director of Critical Infrastructure  
+1.203.564.6561 | ed.levy@nobleiq.com

DISTRIBUTED BY:

MANUFACTURED FOR: VISUAL DETECTION SYSTEMS,  
310 SOUTH GRANT STREET, MINERVA, OHIO 44657

