

Crypton® Finished Upholstery Textiles

Care and Cleaning Instructions

REGULAR MAINTENANCE

It is important to vacuum upholstery regularly to remove loose dirt and surface dust that builds up, before it becomes embedded in the fibers. Use a soft brush to loosen and brush away surface dirt, followed by vacuuming with an upholstery attachment.

SPOT CLEANING TREATMENT

Step 1: Before spot cleaning, blot up liquids on the surface with a clean, soft towel and brush off any loose dirt.

Step 2: Prepare a cleaning solution of 1/4 tsp of a mild, enzyme detergent, such as Tide®, Woolite®, or Dawn® dishwashing liquid, per 1 cup of lukewarm water*. Apply the cleaning solution to the affected area using a spray bottle.

Step 3: Work the solution into the affected area by lightly scrubbing the area with a sponge or soft bristle brush. Make sure to work from the outside of the stain inward so as not to spread the stain, and rinse your sponge or brush frequently.

Step 4: Allow cleaning solution to soak into the fabric. Rinse thoroughly to remove all soap residues, as residues will attract dirt. Blot excess moisture with a clean, soft towel or sponge.

Step 5: Repeat steps 3–4 as needed.

Step 6: Allow fabric to air dry.

**Crypton recommends not using cleaners with acetone and/or hypochlorite as active ingredients, as 5+ exposures in the same area may compromise the moisture barrier.*

STAIN REMOVAL/EXTRACTION CLEANING

The key to removing waterbased or oil-based stains is prompt action. The longer the stain is allowed to remain on a fabric, the more difficult it will be to remove.

Step 1: Prepare the upholstery using the spot cleaning method above to pre-treat any spots. Vacuum the upholstery to remove any loose debris.

Step 2: Prepare a cleaning solution according to the instructions on the chosen extraction concentrate bottle to include the proper dilution ratio. Pour the solution into the tank.

Step 3: Apply solution to fabric by spraying with upholstery wand sprayer.

Step 4: Vacuum up the solution with the upholstery wand vacuum nozzle.

Step 5: Allow fabric to air dry.

Step 6: If any stains remain, repeat the process.